

**Product Name:** Shiki Silk

**Content:** 100% Vinyl with Polyester Knit Backing

**Finish:** Superior Stain Resistance built into the material, not a top-coat

**Cleaning Code:** W/S

Soap and water, alcohol and bleach resistant.

### General Maintenance:

Anzea coated fabrics are inherently stain resistant, however, it is important to keep them clean to maintain the original look and feel. Clean the surface with a detergent or general-purpose cleaner as a first step because it physically removes soil, organic matter, and many germs from the surface. Rinse the surface with clean water or wipe down with a fresh water wipe.

### Approved Cleaners

3M™ C. Diff Solutions Tablets\*  
Accel Prevention®\*  
Accel TB®\*  
Birex® SE  
Bleach Solution\* (20% Dilution)  
Caviwipes™  
Citrace® Germicide\*  
Clorox® Disinfecting Wipes  
Clorox Healthcare® Bleach Germicidal Cleaner & Spray\*  
Clorox Healthcare® EZ Kill Wipes\*  
Clorox Healthcare® Hydrogen Peroxide Disinfectant\*  
Fade-A-Dyne II®  
Fantastik® Spray Cleaner  
Formula 409® All Purpose Cleaner  
Green Works® All Purpose Cleaner  
HealthLink EZ-Kill® Wipes  
Isopropyl Alcohol  
Kay® Solid Sense Sanitizer  
Lysol® Professional Foaming Disinfectant Cleaner  
Lysol® Spray Disinfectant\*  
Neutral Disinfectant Cleaner  
Oasis® 144 Multi-Quat Sanitizer  
Oasis® 146 Multi-Quat Sanitizer  
Optim® 33 TB Disinfectant\*  
Oxivir TB\*  
Oxycide® Daily Disinfectant Cleaner\*  
Perisept®\*  
Purell® Food Service Sanitizer\*  
Sani-Cloth® AF3 Germicidal Disposable Wipes\* (grey top)  
Sani-Cloth® HB Germicidal Disposable Wipes (green top)  
Sani Professional® Multi-Surface Wipes & Spray  
Sani Professional® Table Turners  
SaniZide Plus® Germicidal Solutions  
Simple Green®  
Super Sani-Cloth® Germicidal Wipes\* (purple top)  
Virex® II 256\*  
Virex® Plus\*  
Virox® 5  
Virox® AHP 5 Concentrate/Wipes\*

### Food Stains/Oils

**Mustard. Ketchup. Chocolate. Tea. Coffee. Salad Dressing. Soda.**

Wipe the affected area with a soft cloth or soft bristle brush using a non-abrasive cleaner, for example Formula 409® or Fantastik®. Rinse with fresh water and wipe dry.

### Healthcare/Disinfection

**Blood. Urine. Betadine. Iodine**

Clean with a 10% solution of household bleach and water. Disinfect with a 20% solution of household bleach and water. It is important to rinse the cleaned area with fresh water after applying the bleach solution.

### Difficult Stains

**Mascara. Lipstick. Grease. Oils. Hairspray**

Clean the soiled area with a 70% solution of isopropyl alcohol (rubbing alcohol) and water. It is important to rinse the cleaned area with fresh water and wipe dry.

*\*Denotes those with active ingredients consistent with EPA reports for use against SARS-CoV-2, the virus that causes COVID-19. The efficacy cannot be tested and verified.*

*DO NOT USE: Asepticare TB-11, Cavicide, Clorox Broad Spectrum, Precise Spray, Sani-Cloth® Plus, Sani-Cloth® Bleach Germicidal Wipes or Wex-cide® 128*

**Rinse thoroughly after the suggested waiting period with clean water and wipe with a cloth to dry. Residue left by cleaning agents will degrade, shorten the life and affect the products appearance if not removed.**

Cleaning recommendations above are a guide to product care. Per Anzea's warranty: The warranty does not cover puddling, ink stains, dye stains, cuts, punctures, burns and forms of abuse including those that are unintentional. **The warranty does not cover damage resulting from lack of cleaning, misuse of cleaning agents or the use of inappropriate cleaning agents for the product or the failure to rinse the product after cleaning or disinfecting.**